

Win 8/7 Embedded Driver Installation Instruction Guide

Driver Installation

Follow the instructions to install the driver.

1. Browse the driver CD and go to **Windows Embedded / Win8** or **Win7** folder.
2. Copy the **Mf** folder to your **Local Disk (C: drive)**.
3. Enter the **Mf** folder on your C: drive, and double click  (x64 or x86) according to your version of Windows Embedded.
4. Click **Yes** at User Account Control window if prompted.
5. When the message appears "Do you want to restart...?", press **Y** key.
6. After restarting, browse the CD and go to **Windows Embedded / Win8** or **Win7 / 32-bit** or **64-bit** folder.
7. Run **StnSetup.exe** and follow the on-screen steps to install the driver.